

FD-2240A
6.3MB OPTICAL LINE TERMINATING MULTIPLEXER
PREVENTIVE MAINTENANCE

1. GENERAL

- 1.01 This section is a cover sheet for the NEC America, Inc., FD-2240A 6.3MB Optical Line Terminating Multiplexer Preventive Maintenance. This section is reproduced with permission of NEC America, Inc., and is equivalent to NEC practice NECA 365-407-501, Issue 2.
- 1.02 Whenever this section is reissued the reason(s) for reissue will be listed in this paragraph.
- 1.03 This section provides preventive maintenance instructions and procedures for the FD-2240A 6.3MB Optical Line Terminating Multiplexer (6.3MB O-LTM).
- 1.04 If corrections are required in the attached document, use Form-3973 as described in Section 000-010-015.
- 1.05 If equipment design and/or manufacturing problems should occur, refer to Section SW 010-522-906 for procedures on filing an Engineering complaint.

2. ORDERING PROCEDURE

- 2.01 To order additional copies of this practice, use NECA 365-407-824SW as the section number.

3. REPAIR/RETURN

- 3.01 Malfunctioning units may be returned to NEC America, Inc., for repair.

Attachment: NEC America, Inc.
FD-2240A 6.3MB Optical Line
Terminating Multiplexer
Preventive Maintenance

PROPRIETARY

Not for use or disclosure outside Southwestern Bell
Telephone Company except under written agreement.

**FD-2240A 6.3MB OPTICAL LINE TERMINATING MULTIPLEXER
PREVENTIVE MAINTENANCE**

NEC America, Inc.
Transmission Division

14040 Park Center Road
Herndon, Virginia 22071
Phone No: (703) 834-4000
Fax No: (703) 481-6904
Telex No: 899498
TWX No: 710-831-0639
Easylink No: 62939917

FD-2240A
 6.3MB OPTICAL LINE TERMINATING MULTIPLEXER
 PREVENTIVE MAINTENANCE

CONTENTS

| | Page |
|-----------------------------------|------|
| 1. INTRODUCTION | 2 |
| 2. POWER UNIT VOLTAGE CHECK | 3 |
| 3. REMOVAL OF DUST AND DIRT | 5 |
| 4. ALM LED INDICATION CHECK | 5 |
| 5. LD CURRENT CHECK | 10 |

ILLUSTRATIONS

| Figure | Title | Page |
|--------|---------------------------------|------|
| 2-1 | Power Voltage Check Setup | 4 |
| 5-1 | LD Current Check Setup | 11 |

TABLES

| Table | Title | Page |
|-------|---|------|
| 1-1 | Preventive Maintenance Tasks | 2 |
| 2-1 | Station Power Supply Voltage Ranges | 5 |

Copyright © 1986 by NEC America Inc. All rights reserved.
 This document is not an offer to sell. The information
 contained in this document is subject to change without notice.

TABLES (Cont'd)

Page

2-2 Power Unit Output Voltage Ranges 5

4-1 Alarm LED Indications 6

1. INTRODUCTION

1.01 This practice provides preventive maintenance instructions and procedures for the FD-2240A 6.3MB Optical Line Terminating Multiplexer (6.3MB O-LTM).

1.02 Issue 2 of this practice supersedes Issue 1 of NECA 365-407-501. The practice provides expanded coverage and corrects errors and omissions in the superseded document.

1.03 Whenever this practice is reissued, the reason for reissue will be listed in this paragraph.

1.04 Table 1-1 lists preventive maintenance tasks. Preventive maintenance tasks should be performed at the intervals shown in order to locate, diagnosis, and correct trouble symptoms before they become serious enough to cause unit failure or service interruption. It is recommended that a record form be posted near the equipment for recording task results. The following paragraphs provide preventive maintenance instructions.

Table 1-1
Preventive Maintenance Tasks


| TASK | RECOMMENDED INTERVAL |
|----------------------------|----------------------|
| Power unit voltage check | 6 months |
| Removal of dust and dirt | 6 months |
| Alarm LED indication check | 6 months |
| LD current check | 6 months |

2. POWER UNIT VOLTAGE CHECK


2.01 Refer to Figure 2-1 for checking power supply voltages. Primary power source measurements are made at the back of the shelf. Power unit output voltages are measured at the front panel monitor jack.

2.02 If the FD-2240A operates on -48 or -24 vdc main power supply voltage, use a digital voltmeter to measure voltage at main power terminal X5. If the equipment operates on 117 vac main power, use a digital voltmeter to measure the AC voltage applied to terminal X6. The voltage between the terminal pins of each supply input (MAIN 1 and MAIN 2) should be within the ranges listed in Table 2-1.


2.03 Use a digital voltmeter and voltage test cord to measure the power unit output voltages. The voltages should be within the ranges listed in Table 2-2.



(A) DC (-) Supply Voltage Check



(B) AC Supply Voltage Check



(C) Power Unit Output Voltage Check

Figure 2-1 Power Voltage Check Setup

Table 2-1
Station Power Supply Voltage Ranges

| POWER UNIT TYPE | TEST POINT | ALLOWABLE RANGE |
|-----------------|--|-----------------|
| -24 vdc | MAIN 1 [X5, DC(-)-SG] MAIN 2 [X5, DC(-)-SG] | -21 to -27 Vdc |
| -48 vdc | MAIN 1 [X5, DC(-)-SG] MAIN 2 [X5, DC(-)-SG] | -42 to -56 Vdc |
| 117 vac | MAIN 2 [X6 AC] | 90 to 129 Vac |

Table 2-2
Power Unit Output Voltage Ranges

| OUTPUT VOLTAGE | TEST POINT | ALLOWABLE RANGE | REMARKS |
|----------------|------------|-------------------|---------|
| +5V | +5D | +5.4 \pm 0.45V | DC PWR |
| -9V | -9D | -9.4 \pm 0.65V | |
| +5V | +5V | +5.0 \pm 0.30V | AC PWR |
| -9V | -9V | -9.0 \pm 0.55V | |
| -48V | -48V | -48.0 \pm 2.40V | |

3. REMOVAL OF DUST AND DIRT

3.01 Follow standard shop practices for removal of dust and dirt from electronic equipment. Do not use compressed air to clean the equipment because this tends to circulate as much dust as it removes.

4. ALARM LED INDICATION CHECK

4.01 When ALM unit TST switch is activated, all unit and display panel LEDs are lit. When TST switch is released, alarm LED goes out. Use the following procedures to check the FD-2240A LED indicators and character display:

- (1) Check that CTRL unit SEL switch is set to middle (automatic switching) position.
- (2) Set ALM unit MAINT switch to ON position. MAINT LED is lit.
- (3) Depress and hold ALM unit TST switch. All FD-2240A indicators (except SOURCE and PWR ON LED) are lit. See Table 4-1.
- (4) Release TST switch and verify all alarm indicators are cleared.
- (5) Set MAINT switch to OFF position. MAINT LED goes out.

Table 4-1
Alarm LED Indications

| UNIT | INDICATION | LED | STATUS | |
|------|------------|-------|------------------|---------|
| | | | NORMAL OPERATION | ALM TST |
| ALM | CPU | red | OFF | ON |
| | UNUSED* | amber | OFF | ON |
| | MAINT | red | OFF | ON |
| | SOURCE | green | ON | ON** |
| CTRL | FAIL | red | OFF | ON |
| | LOCK | red | OFF | ON |
| | CH1 | red | OFF | ON |
| | CH2 | red | OFF | ON |

NOTE: * mark is installed only on the Grp: 0A00 unit. On Grp: 0A01 and AA00, this LED is not mounted.

Table 4-1
Alarm LED Indications (Cont'd)

| UNIT | INDICATION | LED | STATUS | |
|------------------|-------------|-------|---------------------------|---------|
| | | | NORMAL OPERATION | ALM TST |
| CTRL (cont'd) | CH3 | red | OFF | ON |
| | CH4 | red | OFF | ON |
| | SELF | red | OFF | ON |
| | OFF LINE | red | OFF | ON |
| DS2 INF | ON LINE | green | ONLINE ON OFF LINE OFF | ON |
| | FAIL | red | OFF | ON |
| | AIS | amber | OFF | ON |
| DMUX | ON LINE | green | ONLINE ON OFF LINE OFF | ON |
| | FAIL | red | OFF | ON |
| | RMT ALM | amber | OFF | ON |
| | RLB DET CH1 | red | OFF | ON |
| | RLB DET CH2 | red | OFF | ON |
| | RLB DET CH3 | red | OFF | ON |
| | RLB DET CH4 | red | OFF | ON |

Table 4-1
Alarm LED Indications (Cont'd)

| UNIT | INDICATION | LED | STATUS | |
|---------------|----------------|-------|--------------------------|-----------|
| | | | NORMAL OPERATION | ALM TST |
| Display Panel | ACO | amber | OFF | ON |
| | LOCAL MAJ | red | OFF | ON |
| | LOCAL MIN | amber | OFF | ON |
| | REMOTE MAJ | red | OFF | ON |
| | REMOTE MIN | amber | OFF | ON |
| | LOCAL DISP | red | OFF | ON |
| | REMOTE DISP | red | OFF | ON |
| | LOCAL DISPLAY | | no inidcation | ***NEC*** |
| | REMOTE DISPLAY | | no indication | FD-2240A |
| MUX | ON LINE | green | ONLINE ON OFFLINE OFF | ON |
| | FAIL | red | OFF | ON |
| | RLB SET | red | OFF | ON |
| 6M OPT INF | ON LINE | green | ONLINE ON OFFLINE OFF | ON |
| | FAIL | red | OFF | ON |

Table 4-1
Alarm LED Indications (Cont'd)

| UNIT | INDICATION | LED | STATUS | |
|------------------------|-------------|-------|------------------|---------|
| | | | NORMAL OPERATION | ALM TST |
| 6M OPT INF (cont'd) | MAJ ERR | red | OFF | ON |
| | RLB DET | red | OFF | ON |
| | RLB SET | red | OFF | ON |
| | LD CURR ALM | amber | OFF | ON |
| PWR | PWR ON | green | ON | ON** |
| SV | RCV 1 FAIL | red | OFF | ON |
| | RCV 2 FAIL | red | OFF | ON |
| | RCV 3 FAIL | red | OFF | ON |
| | RCV 4 FAIL | red | OFF | ON |
| | XMT 1 FAIL | red | OFF | ON |
| | XMT 2 FAIL | red | OFF | ON |
| | XMT 3 FAIL | red | OFF | ON |
| | XMT 4 FAIL | red | OFF | ON |

**Not controlled by test switch.

5. LD CURRENT CHECK

5.01 LD current check is required when the 6M OPT INF unit is of LD type (X0307).

5.02 To do this check, measure output voltage by connecting a voltmeter to the LD CURR MON terminal on the unit front and convert the measured voltage into LD current value. The measurement procedure is as follows. Refer to Figure 5-1.

- (1) Connect a digital voltmeter to the LD CURR MON terminals and read the measured voltage.
- (2) Convert the measured voltage into LD current using the following formula:

$$\text{LD current (mA)} = \frac{\text{Measured voltage (mV)}}{10 \text{ ohm}}$$

5.03 The LD current in normal operation should be within the range 5mA to 120mA (measured voltage 0.05V to 1.2V). LD CURR ALM LED is lit if the bias current exceeds 120mA.




Figure 5-1 LD Current Check Setup