



This schematic was created to show how to wire a Western Electric telephone (Candle Stick, 102 & 202) without a subset box. Obviously there is not a bell or Anti-Sidetone Induction Coil. By wiring a telephone without the coil, you may experience a slight reduction in volume on other extension phone being used at the same time.