

P1 CARRIER TELEPHONE SYSTEM

ADJUSTMENTS AND MAINTENANCE

REPEATERS

PREPARATION FOR CONNECTING TO LINE

1.00 PREPARATION

1.01 Remove board E.

1.02 Place the pads specified by the engineer in the IN and OUT pad positions on boards B and J. For 0-db OUT pad value, strap screw terminals 1 and 3.

1.03 If the tests were performed at a bench location, place the protective cover on the repeater connector (803B) before transporting it to the field.

1.04 For installation and connection information, refer to the section entitled P1 Carrier Telephone System, Installation and Connections, Remote Terminal and Repeater.