

## CODED JACKS—1 THROUGH 199 DESCRIPTION

### 1. GENERAL

**1.01** This section lists and illustrates the coded jacks within the part or type number range of 1 through 199, used for the maintenance and operation of equipment in central offices.

**1.02** The reasons for reissuing this section are listed below. Since this is a major revision, revision arrows have been omitted. The Equipment Test List is not affected.

- (1) To update to the standard BSP format
- (2) To divide this section into smaller sections for easier access and maintainability.

**1.03** Information previously shown in Issue 3 of this practice is now provided in the following sections:

SECTION	TITLE
032-511-104	Coded Jacks—201 Through 249
032-511-107	Coded Jacks—250 Through 299
032-511-110	Coded Jacks—300 Through 349
032-511-113	Coded Jacks—350 Through 399
032-511-116	Coded Jacks—400 Through 449
032-511-119	Coded Jacks—450 Through 474
032-511-122	Coded Jacks—475 Through 499
032-511-125	Coded Jacks—500 Through 549
032-511-128	Coded Jacks—550 Through 574
032-511-131	Coded Jacks—575 Through 599

### SECTION

### TITLE

032-511-134	Coded Jacks—600 Through 624
032-511-137	Coded Jacks—625 Through 649
032-511-138	Coded Jacks—650 Through 700

### 2. DESCRIPTION OF CODED JACKS

**2.01 49:** The 49 strip mounted jack (Fig. 1) is used with 150, 184, 207, 211, 212, 213, and 310 plugs.




Fig. 1—49 Jack

**2.02 50:** The 50 strip mounted jack (Fig. 2) is used with 150, 184B, 212, 213, and 310 plugs. Local contacts are not suitable for talking circuits.




Fig. 2—50 Jack

**2.03 70:** The 70 strip mounted jack (Fig. 3) is used with 150, 184B, 212, and 310 plugs.

### NOTICE

Not for use or disclosure outside the  
Bell System except under written agreement




Fig. 3—70 Jack

2.04 **92:** The 92 strip mounted jack (Fig. 4) is used with 245 and 309 plugs.




Fig. 4—92 Jack

2.05 **112:** The 112 strip mounted jack (Fig. 5) is used with 32, 37, 65, and 78 plugs.




Fig. 5—112 Jack

2.06 **122:** The 122 strip mounted jack (Fig. 6) is used with 310 plug.




Fig. 6—122 Jack

2.07 **138:** The 138 strip mounted jack (Fig. 7) is used with 310 plug.




Fig. 7—138 Jack

2.08 **141:** The 141 strip mounted jack (Fig. 8) is used with 184B, 212, 213, and 310 plugs. The 141 replaced the 166 jack.




Fig. 8—141 Jack