

## CODED TOOLS NO. 597A TO 608B **DESCRIPTION**

TOOL, 597A



Armature Adjuster Replaces the AECo H-14768 tool. For use on step-by-step relays.

TOOL, 598A




Test probe

The No. 419A tool or KS-6278 connecting clip or other suitable connecting clip may be mounted in the chuck of this tool.

For use with the 31-type transmission measuring set.

TOOL, 6004




Short-circuiting tool.

For use on 19-type resistance in allotter circuits.

TOOL, 601A Manufacture Discontinued.

Replaced by the No. 608B tool.

TOOL, 601B



Cut-over tool

For use on U676 and U680 relays in step-bystep dial systems.

Manufacture Discontinued.


TOOL, 602A Manufacture Discontinued.

Replaced by the No. 602B tool.

TOOL, 602B

Replaced by the No. 602C tool.

TOOL, 6020




Amplifier extractor.

Replaces the No. 602B tool.

For use in extracting J68647A amplifiers from mounting plates.

TOOL, 603A



Relay extractor

For use on 275- and 276-type relays.

TOOL, 604A

Manufacture Discontinued

Replaced by the No. 604D tool

TOOL, 604B TOOL, 604C TOOL, 604D

Tape splicers

The No. 604B tool is used to splice unperforated tape in accounting centers.

The No. 6040 tool is used to splice unperforated tape in central offices.


The No. 604D tool is used to splice perforated tape in accounting centers.

For apparatus requirements and adjusting procedures for these tools, refer to Section 076-133-701 covering this apparatus.

Por piece part information for these tools, refer to Section 076-133-801 covering this apparatus.

For use in AMA system.

TOOL, 605A



Soldering tool

For use in maintaining concentricity between the center contact and the body of a 337-type plug while soldering the plug to the center conductor of a coaxial cable.


Page 2 2 Pages TOOL, 606A



Armature tab adjuster

For use on 263- and 264-type relays

TOOL. 607A



Relay winding connector

Replaces the R-2736 relay winding connector.


For use on U-, Y-, UA-, and UB-type relays.

TOOL, 608A

Manufacture Discontinued

Replaced by the No. 608B tool.

\*T00L, 608B



Cut-over tool

Replaces the No. 608A tool.

For use on EA6, EA12 and EA35 relays.