
# TOOLS

### WRENCHES, ADJUSTABLE – DESCRIPTION

## 1. GENERAL

- This section covers coded and noncoded 1.01 Bell System adjustable wrenches.
- When this section is reissued, the reason for 1.02 reissue will be listed in this paragraph.
- The information contained in this section 1.03 supersedes the corresponding information in Sections 074-126-101 and 074-860-101.
- See tool index for other Wrench practices. 1.04



Adjustable strap wrench. For use by telephone repairmen and installers for tightening and loosening the transmitter caps on handsets.


#### R-1538 R-1539

In ordering, specify number of wrench desired.

	<b>₽₽</b> ₩		
WRENCH	MAX CAPACITY	LENGTH (INCHES)	
R-1538	1-inch pipe	10	
R-1539	2-inch pipe	18	
For use on com	pressor sets.		

#### R-1542 R-2512


In ordering, specify number of wrench desired.



WRENCH	MAX OPENING (INCHES)	APPROX LENGTH (INCHES)
R-1542	3/4	6
R-2512	15/16	8


Adjustable wrenches. The R-1542 is for general use in power plants. The R-2512 is for general use.

#### R-2652



A 9-inch adjustable auto or thin monkey-type wrench. Maximum opening is 2-5/8 inches. Replaces the No. 9, Model G, Billings and Spencer wrench. For use on AMA KS-13928 cleaning cabinet.

## NOTICE Not for use or disclosure outside the Bell System except under written agreement



Works 8-inch pipe wrench.