



EQUIPMENT TEST LIST
TRANSMISSION TRUNKS
NO. 4A AND 4M TOLL SWITCHING SYSTEMS

	CONTENTS	PAGE
1. GENERAL	1
7.1 4A	2
7.2 4M	2
7.3 IMTF	3
7.4 PLUG-IN	3
7.5 MISC	3

1. GENERAL

1.01 This section provides an index and information access system to locate the standard tests applicable to equipment listed in the preceding table

of contents. Test classification and frequency of periodic routine are also provided.

1.02 This Equipment Test List (ETL) is reissued to incorporate changes which are indicated by an arrow to the left of each line which has been changed.

1.03 Comments on this section should be made by following the instructions in Bell System Practices (BSP), Section 000-010-015.

1.04 Routine test information is arranged in the following order from left to right: Section number, issue/addendum, test letter or paragraph number, test title, test class, frequency, and the last space is for a locally assigned job number.

1.05 Section 010-300-011 provides Equipment Test List instructions.

NOTICE

Not for use or disclosure outside the
Bell System except under written agreement

7.0 TX TRUNKS

7.1 TX TRUNKS; 4A

AOCT SD-68373-01

FOR ALL UNITS

212-566-501	(7/0)	E	**TF TEST**TRUNK IDENTIFICATION	MW 12M	-----
		J	**TF TEST**TX TRUNKS-DP	MW 12M	-----
		K	**TF TEST**TX TRUNKS-MFP OR EMPLOYING OUTGOING SDR	MW 12M	-----
		M	**TF TEST**TRUNK VERIFICATION	MW *	-----
212-566-502	(5/1)	C	PAD CONTROL	MW 12M	-----
		D	PAD CUT-IN RELAY	MW 12M	-----
		J	MAKE-BUSY	MW 12M	-----

OPTIONAL FEATURES

TRKS ASSOCIATED WITH OUTGOING SNDRS

212-566-501	(7/0)	C	**TF TEST**EARLY RELEASE	MW *	-----
		D	**TF TEST**REORDER	MW *	-----

AOTT SD-68580-01

FOR ALL UNITS

212-566-503	(2/0)	E	**TF TEST**TRUNK IDENTIFICATION	MW *	-----
212-566-505	(1/1)	D	**TF TEST**DP REP SUP AND RERING	MW *	-----
		E	**TF TEST**MF OR OUT SDR SUP AND RERING	MW *	-----
		I	**TF TEST**TRUNK VERIFICATION	MW *	-----
		L	**TF TEST**PAD CONTROL	MW *	-----
		M	**TF TEST**PAD CUT-IN	MW *	-----
		P	**TF TEST**MAKE BUSY	MW *	-----

OPTIONAL FEATURES

TRKS ASSOCIATED WITH OUTGOING SNDRS

212-566-503	(2/0)	C	**TF TEST**EARLY RELEASE	MW *	-----
		D	**TF TEST**REORDER	MW *	-----

7.2 TX TRUNKS; 4M

ATCT SD-68076-01

FOR ALL UNITS

212-566-501	(7/0)	E	**TF TEST**TRUNK IDENTIFICATION	MW *	-----
		K	**TF TEST**TX TRUNKS-MFP OR EMPLOYING OUTGOING SDR	MW *	-----
		M	**TF TEST**TRUNK VERIFICATION	MW *	-----
212-566-502	(5/1)	C	PAD CONTROL	MW 12M	-----
		D	PAD CUT-IN RELAY	MW 12M	-----
		E	LOCK-OUT TEST	MW 12M	-----
		J	MAKE-BUSY	MW 12M	-----

OPTIONAL FEATURES

TRKS ASSOCIATED WITH OUTGOING SNDRS

◆	212-566-501 (7/0)	C	**TF TEST**EARLY RELEASE	MW *	-----
◆		D	**TF TEST**REORDER	MW *	-----
◆	AOTT SD-68580-01				
◆	FOR ALL UNITS				
◆	212-566-503 (2/0)	E	**TF TEST**TRUNK IDENTIFICATION	MW *	-----
◆	212-566-505 (1/1)	E	**TF TEST**MF OR OUT SDR SUP AND RERING	MW *	-----
◆		I	**TF TEST**TRUNK VERIFICATION	MW *	-----
◆		L	**TF TEST**PAD CONTROL	MW *	-----
◆		M	**TF TEST**PAD CUT-IN	MW *	-----
◆		P	**TF TEST**MAKE BUSY	MW *	-----
◆	OPTIONAL FEATURES				
◆	TRKS ASSOCIATED WITH OUTGOING SNDRS				
◆	212-566-503 (2/0)	C	**TF TEST**EARLY RELEASE	MW *	-----
◆		D	**TF TEST**REORDER	MW *	-----
◆	7.3 TX TRUNKS; IMTF				
◆	FOR ALL UNITS				
◆	212-571-504 (3/0)	A	**TF TEST**TEST LINE	MW *	-----
◆		B	**TF TEST**BUSY LINE	MW *	-----
◆		C	**TF TEST**INCOMING RELEASE	MW *	-----
◆		D	**TF TEST**TRUNK VERIFICATION	MW *	-----
◆		E	**TF TEST**OVS LOOP-AROUND TRUNKS	MW *	-----
◆	7.4 TX TRUNKS; PLUG-IN				
◆	TROUBLE TESTS				
◆	212-502-501 (3/0)	A	OPR TST--4A TRK UNITS SD-68595-01	TT	-----
◆		B	TRNSM TST--4A & 4M TRK UNITS	TT	-----
◆		C	OPR TST--4M TRK UNITS SD-68596-01	TT	-----
◆		D	GUARD REL RLS TIME--4M TRK UNITS SD-68596-01	TT	-----
◆		E	OBSERVING IN-SERVICE & TEST CALLS	TT	-----
◆	7.5 TX TRUNKS; MISC				
◆	TROUBLE TESTS				
◆	212-567-503 (2/0)	A	E&M LEAD SIGNALING TSTS	TT	-----
◆		B	DIRECT PULSE DIAL	TT	-----
◆		C	MANUAL & SVC BUSY OVERRIDE	TT	-----
◆		D	COMM TRK & TRK HOLD	TT	-----
◆		E	REORDER TEST	TT	-----
◆		F	MTF TO MLCP LOOP TEST (SMAS ONLY)	TT	-----