# 300-MEGABYTE MOVING HEAD DISK DRIVE KS-22707,L1

# PREVENTIVE MAINTENANCE 3B20D MODEL 2 PROCESSOR

	CONTENTS								PAGE					
1.	GENERAL							•	•	•		•	1	
Tabk	es													
A.	Preventive	e M	inic	en	anc	e S	erv	ice	s				1	

# 1.04 Preventive maintenance services required by the manufacturer are provided in the manual and are recapitulated in Table A. Where a conflict exists, the preventive maintenance services in the manufacturer's manual shall take precedence.

## PREVENTIVE MAINTENANCE SERVICES

TABLE A

TEST	TITLE	FREQUENCY
1	Clean Primary Air Intake Filter	3 Months
2	Check +5 Volt and -5 Volt Outputs	3 Months
3	Clean Shroud and Spindle	6 Months
4	Clean and Lubricate Lockshaft	6 Months
5	Clean Carriage Rails and Bearings	6 Months
6	Replace Absolute Air Filter	1 Year

# 1. GENERAL

- 1.01 This section is a cover sheet for manufacturer operating and service manuals for the KS-22707,L1 moving head disk. This moving head disk is a component of the 3B20D Model 2 processor. Copies of manufacturer manuals are supplied with each moving head disk. Additional copies can be ordered from parts lists by part number.
- 1.02 Whenever this section is reissued, the reasons for reissue will be listed in this paragraph.
- 1.03 Descriptive, theory of operation, installation, and operating information and maintenance instructions for the moving head disk are given in the manufacturer's manuals.

# NOTICE

Not for use or disclosure outside the Bell System except under written agreement