



**NODAL TIMING SUPPLY  
DESCRIPTION  
DIGITAL DATA SYSTEM**

**1. GENERAL**

**1.001** This addendum supplements Section 314-913-110, Issue 1. Place this pink sheet ahead of Page 1 of the section.

**1.002** This addendum is issued for the following reasons:

- (a) To change the section title
- (b) To change paragraph 1.02 to paragraph 1.03 and replace paragraph 1.02 with the standard paragraph
- (c) To add information regarding the nonredundant timing input of the D-type channel bank bay
- (d) To add a warning about the consequences of removing a power unit when the office is equipped for dataport operation
- (e) To add a warning about the consequences of removing circuit packs HL-58 and HL-59 when the office is equipped for dataport operation
- (f) To change panel at the bottom of Fig. 2 to unit
- (g) To correct a section number in the list of references in paragraph 4.01.

**2. CHANGES TO SECTION**

**2.001** On Page 1, change the section title to Nodal Timing Supply, Description, Digital Data System

**2.002** On Page 1, change paragraph 1.02 to 1.03 and replace paragraph 1.02 with the standard

paragraph which states: When this section is reissued, the reason(s) for reissue will be given in this paragraph. Renumber the remaining paragraphs in Part 1.

**2.003** On Page 3, at the end of paragraph 2.04, add the following: An exception is a D-type channel bank bay, equipped for dataport operation which has nonredundant timing inputs.

**2.004** On Page 3, at the end of paragraph 2.04, add the following:

***Warning 1: Whenever the 74A or 78A power unit is removed, all dataport channels within a specific office connected to the A-side or B-side taps of the timing supply are dropped from service.***

**2.005** On Page 3, at the end of paragraph 2.04, after Warning 1, add the following:

***Warning 2: When circuit packs HL-58 and HL-59 are removed, all dataport channels connected to the timing supply will drop out of service.***

**2.006** On Page 3, Fig. 2, change the designations in the lower block from DISPLAY AND CONTROL PANEL to DISPLAY AND CONTROL UNIT.

**2.007** On Page 13, Part 4 REFERENCE, add the words SECTION over the BSP number column and TITLE over the title column.

**2.008** On Page 13, at the end of reference paragraph 4.01, change section number 886-100-110 to 880-601-110.

**NOTICE**

Not for use or disclosure outside the  
Bell System except under written agreement