

LIBRARY  
FILE COPY

**NODAL TIMING SUPPLY  
MAINTENANCE AND TROUBLESHOOTING  
DIGITAL DATA SYSTEM**

**GENERAL**

**1.001** This addendum supplements Section 314-913-310, Issue 1. Place this pink sheet ahead of Page 1 of the section.

**1.002** This addendum is issued for the following reasons:

- (a) To change the section title
- (b) To change paragraph 1.02 to 1.03, replace paragraph 1.02 with the standard paragraph, and renumber the remaining paragraphs in Part 1
- (c) To add information regarding the nonredundant timing input of the D-type channel bank bay
- (d) To add a warning about the consequences of removing a power unit when the office is equipped for dataport operation
- (e) To add a warning about the consequences of removing circuit packs HL-58 and HL-59 when the office is equipped for dataport operation
- (f) To change the word panel to unit throughout the section.

**2. CHANGES TO SECTION**

**2.001** On Page 1, change the section title to Nodal Timing Supply, Maintenance and Troubleshooting, Digital Data System.

**2.002** On Page 1, change paragraph 1.02 to 1.03 and replace 1.02 with the standard paragraph

which states: When this section is reissued, the reason(s) for reissue will be given in this paragraph. Renumber the remaining paragraphs in Part 1 of the section.

**2.003** On Page 2 after paragraph 4.03, add the following: The D-type channel bank bay, equipped for dataport operation has nonredundant timing inputs which may cause trouble when power units and circuit packs are removed.

**2.004** On Page 1 after paragraph 1.03 and Page 12 before Step 1 of Chart 10, add the following:

**Warning 1:** *Whenever the 74A or 78A power unit is removed all dataport channels within a specific office connected to the A-side or B-side taps of the timing supply are dropped from service.*

**2.005** On Page 1 after paragraph 1.03 and Page 12 before Step 1 of Chart 11, add the following:

**Warning 2:** *When circuit packs HL-58 and HL-59 are removed, all dataport channels connected to the timing supply will drop out of service.*

**2.006** On Page 2 in the heading above paragraph 4.04, paragraphs 4.04 and 4.07, Page 4, paragraph 5.04, and Page 20, paragraphs 5.17 and 5.18, change the word panel to unit.

**2.007** On Page 3, paragraph 4.13 and Page 4, paragraph 5.03, change circuit pack HL49(Mfr Disc) to HL49B.

**NOTICE**

Not for use or disclosure outside the  
Bell System except under written agreement