



SIMPLIFIED USER GUIDE PARTNER® PagePac®

OPERATION

Accessing the System

- Dry Loop Mode: dial [INTERCOM] [7][0]
- Station Mode: dial [INTERCOM] station no.
- Trunk Adapter Mode: dial [LINE]
(If a Connect Password is enabled, you will hear a special tone. Enter the Connect Password.)
You should hear the PARTNER PagePac dial tone.

Paging

1. Lift the receiver and access the system (see Accessing the System, above).
2. Dial the zone or zone group code:
[1] for zone 1 [4] for zones 2 and 3
[2] for zone 2 [5] for zones 1 and 3
[3] for zone 3 [6] for zones 1 and 2
 [7] for all zones
3. Make page.
4. Gently replace the receiver.

Talkback

1. Follow steps 1 and 2 of Paging.
2. Make page or listen to speaker at talkback zone.
3. Gently replace the receiver.

Microphone Page

1. Turn on the microphone.
2. Make page.
3. Turn off the microphone.

Night Bell

Pick up any ringing phone on line configured for Night Bell

Door Bell

- Door Alert Mode:
Dial into the system (see Accessing the System, above).
- Ring Down Mode:
Pick up the ringing extension.

Door Ajar

- Door Alert Mode:
 1. Dial into the system (see Accessing the System, above)
 2. Enter any touch-tone digit
- Ring Down Mode:
 1. Pick up the ringing extension
 2. Dial any touch-tone digit

Door Unlock

Enter Door Unlock Code

Silent Monitor

1. Follow steps 1 and 2 of Paging.
2. Monitor conversation at Doorspeaker zone.
3. Gently replace the receiver.

PROGRAMMING

Selecting System or Zone Options

1. Lift the receiver and access the system (see Accessing the System, above).
2. Dial [*][*] (followed by the programming password, if one has been configured).
3. Dial appropriate buttons to change or verify an option (see Programming Options on back). You should hear the Configuration tone (two beeps).
4. For Zone Options only: Dial the zone number. You should hear the Configuration tone.
5. Dial the appropriate value (see Programming Options on back). You should hear the Configuration Complete tone (three beeps).
6. Dial [#] to end programming.

Comcode-406980763

CIC 403-248-205

OII726070-001, Issue 1



PROGRAMMING OPTIONS

SYSTEM PROGRAMMING OPTIONS		
SYSTEM OPTION	ACTION	VALUE
Connect Password	[3][0] to change; [3][1] to verify	Zero to six touch-tone digits; terminated by [#] if fewer than six digits specified
Programming Password	[3][2] to change; [3][3] to verify	Zero to six touch-tone digits; terminated by [#] if fewer than six digits specified
Door Unlock Code	[3][4] to change; [3][5] to verify	One to four touch-tone digits; terminated by [#] if fewer than six digits specified
Confirmation Tone Enabled	[4][0] to change; [4][1] to verify	[0] to disable; [1] to enable
Pre-Announcement Tone	[4][2] to change; [4][3] to verify	[0] to disable; [1] to enable
Talkback Warning Tone Enabled	[4][4] to change; [4][5] to verify	[0] to disable; [1] to enable
Reset to Factory Defaults	[1][0] to configure	[2][5][3][2][7] ([C][L][E][A][R])

ZONE PROGRAMMING OPTIONS			
ZONE OPTION	ACTION	ZONE NUMBER	VALUE
Type of Zone	[6][0] to change; [6][1] to verify	[1] or [2]	[1] for Page/Speaker [2] for Doorspeaker [3] for Remote Amp
Door Action	[6][2] to change; [6][3] to verify	[1] or [2]	[1] for Door Alert [2] for Ring Down
Page/Tone Level	[6][4] to change; [6][5] to verify	[1] or [2]	[1] through [8] for Amplifier Level
Music Level	[6][6] to change; [6][7] to verify	[1] or [2]	[1] through [8] for Amplifier Level
Station Page Enabled	[7][2] to change; [7][3] to verify	[1], [2], or [3]	[0] to disable; [1] to enable
Music Enabled	[7][4] to change; [7][5] to verify	[1], [2], or [3]	[0] to disable; [1] to enable
Talkback Enabled	[7][6] to change; [7][7] to verify	[1] or [2]	[0] to disable; [1] to enable
Night Bell Enabled	[7][8] to change; [7][9] to verify	[1], [2], or [3]	[0] to disable; [1] to enable
Pass DTMF to Zone Enabled	[9][0] to change; [9][1] to verify	[1], [2], or [3]	[0] to disable; [1] to enable
Microphone Page Enabled	[9][2] to change; [9][3] to verify	[1], [2], or [3]	[0] to disable; [1] to enable
Door Alert Enabled	[9][4] to change; [9][5] to verify	[1], [2], or [3]	[0] to disable; [1] to enable