

TABLE A
LINE, RINGER, AND TUBE CONNECTIONS

WIRE OR LEAD		COLOR	NEGATIVE (-) RING PARTY*	POSITIVE (+) RING PARTY*
			1-5	3-7
			RING	RING
Ringer Leads		R BK S S-R	E E K A	A K E E
Line Switch		S	A	A
426A Tube (3-Element)		R BK Y	L1 or G G E	A E G
Mtg Cord in Set		R G Y	L2 L1 G	L2 L1 G
Mtg Cord at Conn Block		R G Y	R G Y	R G Y
Line Wire at Conn Block	Ring Tip GRD	R G Y	R G Y	R G Y

* For tip party stations reverse (G) and (R) mounting cord leads.

Note: Factory-wired for negative tip or ring station.