1A1 KEY TELEPHONE SYSTEM LAMP WINK CIRCUIT USING 202A, B, C, D; WITH 210A AND 212A KEY TELEPHONE UNITS

CONNECTIONS

1.00 GENERAL

- 1.01 This section covers connections required at the apparatus cabinet for the lamp wink circuit. This includes strapping between the key telephone units and terminating of wires from power sources.
- 1.02 This section is reissued to include connections for 202C and D key telephone units.←
- 1.03 The data shown in this section at the time of its issuance reflects the latest wiring connection arrangements. In some cases these connections are not consistent with those shown on existing drawings.

2.00 CONNECTIONS

2.02 The connection drawing shows the necessary terminations to be made for power and cross-connection straps within and between key telephone units (see Fig. 2).

3.00 DESCRIPTION OF OPERATION

Lamp Wink Circuit: When a line is held, ground is placed on the HA lead, operating the WS relay, and the signal lamp is connected to the W relay. Operation of the WS relay starts the flashing circuit and connects ground to a contact of the FB relay. When the FB relay operates, it operates the W relay under control of the WT relay. Operation of the W relay extinguishes the lamps and operates the WT relay. The WT relay locks operated under control of the FB relay and releases the W relay, which lights the lamps again. When the FB relay releases, it releases the WT relay, and the cycle repeats for each operation of the FB relay. The lamp circuit is opened for approximately 30 milliseconds once per second.




Fig. 1 — Lamp Wink Circuit — 210A and 212A Key Telephone Units

202C OR D= K T U 202A= 212A K T U TS A B C 202B = 210A K T U KTU LW (10A) 1 LB 2 (9A) LW (юв) 3 LB (9B) 4 LW (oc) 5 LB **9**C 6 LW 7 202 A,B,C OR D LB 8 LW 9 2ND LB 202 A,B,C OR D 10 (38B) $\overline{\Pi}$ S (37B) [12] F (37A) (13 то (21 14 HA 15 16 BAT. [18] <u>G RD</u> (20)

ALL STRAPS SHOWN SHALL BE ADDED TO OBTAIN FEATURES DESIRED.

Fig. 2 — Connections — 202A, B, C, D; with 210A and 212A Key Telephone Units

Note: Wink circuit for sixth line not provided unless second 210A KTU is provided.

Remove the following Z wiring straps if in place:

202A KTU - Term. 26-27

202B KTU — Term. 9-10

202C or D KTU — Term. 20 — Disconnect Lamp Battery

212A KTU — Term. 9-10, 27-37

References:

SD-69288-01

SD-69203-01

SD-69270-01