/

į

NONZONE TEST TIMERS NO. 1C AND D-99325, COIN TEST TIMERS NO. 1D AND D-99326, AND ASSOCIATED NOS. 51B, 51D, 52B, D-156125, AND D-179539 DRIVES

REQUIREMENTS AND ADJUSTING PROCEDURES

1. GENERAL	CODE OR SPEC NO.
1.001 This addendum supplements Section 030-140-703, Issue 4-D.	TOOLSDESCRIPTIONR-2653No. 5 Bristol Setscrew Wrench
1.002 This addendum is issued to:Revise 2.15(a)	— 4-inch) E (Screwdriver
Revise 2.15(a)Revise tool information	 — 5-inch ♦E♦ Screwdriver — 6-inch ♦C♦ Screwdriver
 Revise 3.15(1) Delete 3.29(2). 	
2. CHANGES TO SECTION	 2.003 On Page 17, revise 3.15(1) as follows. 3.15 <i>Gear Stop Pawl Position</i> (Reqt 2.15)
 ISSUE 1 CHANGES 2.001 On Page 5, revise 2.15(a) as follows. (a) With the endplay of the timer gear taken 	 (1) If the pawl does not drop freely from the gear stop, clean the pawl by applying a few drops of petroleum spirits at the pawl bearing, between the pawl and the gear and between the pawl and the mounting bracket using a toothpick.
up toward the mounting bracket, ♦with the pawl on the gear stop and with the pawl spring blocked with a thinned orange stick so that the pawl spring does not touch the pawl, the pawl shall drop freely off the gear stop to the pawl stop when the gear is rotated one revolution.	 Note: The pawl spring tension shall not be used to compensate for pawl binding. (2) Remove the timer (3.003) to check or adjust the pawl spring tension. Use the 485A pliers to change the tension in the pawl spring to meet requirement 2.15(d).
Gauge by eye. 2.002 On Page 13, revise 3.001 as follows.	(3) If requirements cannot be met, refer the matter to the supervisor. When requirements are met, remount the timer (3.003) and ensure
3.001 List of Tools, Guages, Materials, and Test Apparatus	 that requirements 2.06, 2.07, 2.08, 2.10, 2.14, 2.29, and 2.32(b) are met. 2.004 On Page 19, delete 3.29(2).

NOTICE

Not for use or disclosure outside the Bell System except under written agreement